

Townsend, Ceiling Oil Fire

Oil Fire, smoke damaged ceiling and wall in Kitchen, Dinning room.
Clean with soapy water, precoat with Master Prep Sealing Stain, paint with Ceiling white and colour match walls.



